

Enter 2-line Welcome Message

Menu Settings for UV-5R

Close External Setting Files Tabs Help

Common

☒ Auto Lock

☐ Beep

☒ Busy Channel Lockout

☒ Menu in Channel Mode

☒ FM Radio Enabled

☒ Key Lock

☒ Dual Watch Enable

☒ Reset Enabled

Welcome Message: Basic

A Band Display Mode: Channel+Name

B Band Display Mode: Channel+Name

Alarm Mode: ☐ Sound Site

Number of Channels: 128

Battery Save: 1.2

Backlight (ABR): 5 seconds

Rx Backlight: Blue

Tx Backlight: Orange

Wait Backlight: Off

Power On Message: Welcome

PTT ID: Off

PTT Delay: 0

Roger: Off

Scan Resume: Time

Squelch Level: 5

Time Out Timer: 60 secs

Tx Dual Watch: Off

Tail Tone: Off

Tail Tone (Repeater): Off

Tail Tone Delay: Off

Voice: Off

VOX: Off

DTMF Encode

1	20202
2	11111
3	22222
4	33333
5	44444
6	55555
7	66666
8	77777
9	88888
10	99999
11	12121
12	34343
13	56565
14	78787
15	30303

DTMF-ST: DT-ANI

DTMF Speed

On Time: 80 ms

Off Time: 80 ms

ANHD

☐ Press PTT to Send

☐ Release PTT To Send

Number:

- Under “settings” choose “radio menu settings.”
- Your default menu settings should look like this with the exception of the “welcome message.”
- Your original radio programming file that your received should look like this.